


- Damper range: ø100 till 315.
- Damper can be installed with blade in any position.
- Damper can be installed with mechanism on either side of the wall

360°

- Please consult with the fire batt manufacturer for appropriate sealant/
- For larger wall openings. See CR60 Fire Damper Technical Datasheet.
- A max. of 4 fire dampers can be installed at tested minimal distances from an adjacent horizontal or vertical (supporting) construction or another fire damper. Blade horizontal or max. 45°. See detailed guidelines in the CR60 Technical Datasheet.



- To be read in conjunction with the CR60 Fire Damper Technical
- Guidelines acc. to DW144/145 (not required for CE):
  - 1 installation lug is included by default. A 2nd lug, as shown in the drawings, is available upon request.
  - Provide appropriate break-away / flexible joint between fire damper and connecting ductwork on both sides of the assembly (DW145: eg socket & spigot or flanged with appropriate fixings eg plastic cleats, clips, clamps, bolts, aluminium alloy rivets etc.).
  - Provide a panel in the adjacent ductwork to allow access to the internal components of the fire damper.
  - Ductwork must be independently supported and installed
- · Dimensions in mm unless otherwise stated.



CR60 fire damper in rigid supporting construction. Installation detail with fire batt.

CLASSIFICATION		
El 60/90 (ve i <b>←→</b> o)S		
REV	DATE	Rf-t Rf-Technologies
В	22/04/2024	Ki-Technologies

